


Make: AVR Programming



Learning to Write Software for Hardware
Elliot Williams

Make: AVR Programming

If you've been using an Arduino in your projects and you need more speed, real-time response to external events, or the ability to multitask, it's time for you to take the next step. Learn to use the full power of the AVR microcontrollers that lie at the heart of the wildly popular Arduino hardware.

This book will get you using Atmel's AVR series microcontrollers to their fullest. Discover how the AVR's built-in hardware peripherals can help you solve your project design problems. Take advantage of all that the AVR's have to offer; write your own programs in C, and work directly with the hardware rather than abstracting it away.

But AVR Programming is about more than just programming microcontrollers. This project-oriented book will also show you how to build circuits that interface with the outside world. Before long, you'll be applying what you've learned and experimenting with new ideas!

In *Make: AVR Programming*, you'll learn microcontroller basics, but you'll also move on to intermediate and advanced projects:

- » Respond instantly to as many external events as your AVR has pins
- » Build an inexpensive footstep detector
- » Build circuitry to drive DC and stepper motors as well as other demanding loads
- » Make your projects talk by storing voice sample data in the AVR's non-volatile memory
- » Learn to speak SPI and I2C

If you've had some experience programming an Arduino, and you'd like to get to know the AVR chip more intimately, this book is for you.

Learn the hardware, apply the hardware, love the hardware.

US \$44.99 CAN \$47.99

ISBN: 978-1-4493-5578-4



Make:
makezine.com

Make: AVR Programming

Elliot Williams



Make: AVR Programming

by Elliot Williams

Copyright © 2014 Elliot Williams. All rights reserved.

Printed in the United States of America.

Published by Maker Media, Inc., 1005 Gravenstein Highway North, Sebastopol, CA 95472.

Maker Media books may be purchased for educational, business, or sales promotional use. Online editions are also available for most titles (<http://my.safaribooksonline.com>). For more information, contact O'Reilly Media's corporate/institutional sales department: 800-998-9938 or corporate@oreilly.com.

Editor: Patrick Di Justo

Production Editor: Kara Ebrahim

Copyeditor: Kim Cofer

Proofreader: Amanda Kersey

Indexer: Judy McConville

Cover Designer: Shawn Wallace

Interior Designer: Monica Kamsvaag

Illustrator: Rebecca Demarest

February 2014: First Edition

Revision History for the First Edition:

2014-01-24: First release

2014-02-14: Second release

See <http://oreilly.com/catalog/errata.csp?isbn=9781449355784> for release details.

The Make logo and Maker Media logo are registered trademarks of Maker Media, Inc. *Make: AVR Programming* and related trade dress are trademarks of Maker Media, Inc.

Many of the designations used by manufacturers and sellers to distinguish their products are claimed as trademarks. Where those designations appear in this book, and Maker Media, Inc., was aware of a trademark claim, the designations have been printed in caps or initial caps.

While every precaution has been taken in the preparation of this book, the publisher and authors assume no responsibility for errors or omissions, or for damages resulting from the use of the information contained herein.

ISBN: 978-1-449-35578-4

[LSI]

Table of Contents

Preface	xi
----------------------	-----------

Part I. The Basics

1. Introduction	3
What Is a Microcontroller? The Big Picture	3
A Computer on a Chip.....	3
...But a Very Small Computer	4
What Can Microcontrollers Do?	5
Hardware: The Big Picture	5
The Core: Processor, Memory, and I/O	8
Peripherals: Making Your Life Easier	9
2. Programming AVR.....	13
Programming the AVR	13
Toolchain	14
The Software Toolchain	16
Linux Setup	18
Windows Setup	18
Mac Setup	18
Arduino Setup	18
Make and Makefiles	19
AVR and the Arduino	20
Arduino Pros	20
Arduino Cons	20

The Arduino: Hardware or Software? Both!	23
The Arduino Is an AVR	23
The Arduino Is an AVR Programmer	25
Other Hardware Programmers	28
Flash Programmers I Have Known and Loved	28
Getting Started: Blinking LEDs	29
Hookup	30
ISP Headers	33
AVRDUDE	35
Configuring Your Makefile	38
Flash	40
Troubleshooting	40
3. Digital Output	43
blinkLED Redux	44
The Structure of AVR C Code	45
Hardware Registers	46
blinkLED Summary	49
POV Toy	49
Building the Circuit	50
Pretty Patterns: The POV Toy Code	54
Experiment!	56
4. Bit Twiddling	59
Working Through the Code: Cylon Eyes	60
Bit Twiddling and Cylon Eyes	61
Bit Shifting	62
Advanced Bit Twiddling: Above and Beyond Cylon Eyes	64
Setting Bits with OR	67
Toggling Bits with XOR	69
Clearing a Bit with AND and NOT	70
Showing Off	71
Summary	75
5. Serial I/O	77
Serial Communication	77
Implementing Serial Communication on the AVR: Loopback Project	81
Setup: Configuring the AVR	81
Setup: Your Computer	83
Setup: USB-Serial Adapter	83
Putting It All Together: Test Out Your Loopback	86
Troubleshooting Serial Connections	87
Configuring USART: The Nitty-Gritty Details	88
AVR Square-Wave Organ	95
Making Music with Your Micro	96

The Organ Library	98
The Code	99
Extra Goodies	102
Summary	103
6. Digital Input	105
Pushbuttons, Switches, Etc.	105
Configuring Input: DDRs, PORTs, and PINs	108
Interpreting Button Presses	109
Changing State	112
Debouncing	113
Debounce Example	115
AVR Music Box	117
The Code	117
Boss Button	119
Desktop-side Scripting	120
Extensions	124
7. Analog-to-Digital Conversion I	125
ADC Hardware Overview	126
Light Meter	129
The Circuit	129
The Code	135
ADC Initialization	137
Extensions	139
Slowscope	140
The AVR Code	141
The Desktop Code	143
Synergies	145
AVR Night Light and the Multiplexer	145
Multiplexing	145
Setting the Mux Bits	146
The Circuit	148
The Code	148
Summary	150

Part II. Intermediate AVR

8. Hardware Interrupts	153
External Interrupts 101: Real-time Button Pressing Examples	155
External Interrupt 0 Example	156
Pin-Change Interrupt Example	161
Capacitive Sensor	164
The Sensor	165

The Code	168
Global, Volatile Variables	170
Debugging the Circuit	173
9. Introduction to the Timer/Counter Hardware	175
Timer/Counters: Why and How?	175
Test Your Reaction Time	178
Using Timer 0 for a Better 8-Bit Organ	182
AM Radio	186
The Circuit	188
CPU Speed	189
AM Radio: The Code	190
Summary	196
10. Pulse-Width Modulation	199
Bright and Dim LEDs: PWM	200
Brute-Force PWM Demo	202
Timers PWM Demo	204
Initializing Timers for PWM Mode	206
PWM on Any Pin	208
PWM on Any Pin Demo	209
Closing: Alternatives to PWM and a Timer Checklist	211
11. Driving Servo Motors	215
Servos	216
The Secret Life of Servos	217
The Circuit	218
The Code	219
Servo Sundial	223
The Build	224
Ready the Lasers!	227
The Code	229
Servo Sundial Calibration	236
12. Analog-to-Digital Conversion II	243
Voltage Meter	244
The Circuit	245
The Code	248
The Footstep Detector	252
The Circuit	253
The Theory	258
Exponentially Weighted Moving Averages	259
The Code	262

Summary	266
---------------	-----

Part III. Advanced AVR Topics

13. Advanced PWM Tricks	269
Direct-Digital Synthesis	270
Making a Sine Wave	274
Next Steps: Mixing and Volume	277
Mixing	277
Dynamic Volume Control	280
Polling USART	283
ADSR Envelope	283
Auxiliary Files	284
14. Switches	287
Controlling Big Loads: Switches	288
Bipolar-Junction Transistors	290
MOSFETs	291
Power MOSFETs	293
Relays	294
Triacs and SSRs	295
Switches: Summary	296
DC Motors	297
15. Advanced Motors	305
Going in Reverse: H-Bridges	306
Code: Taking Your H-Bridge Out for a Spin	309
Experts-Only H-Bridge	312
PWM and the H-Bridge	313
Drive Modes: Sign-Magnitude	314
Drive Modes: Locked Anti-phase	314
Drive Modes: Comparison	315
Stepper Motors	318
Kinds of Stepper Motors	319
Full Stepping and Half Stepping	320
Identification of Stepper Motor Wires	323
Too Many Wires!	323
Dual H-Bridge Chips: The SN754410	325
The Code	327
Acceleration Control	331
Microstepping	334
16. SPI	337
How SPI Works	338

Bit Trading Example	340
Shift Registers	340
EEPROM External Memory	343
External Memory	344
SPI Demo Hookup	347
SPI Demo Code	348
SPI EEPROM Library Header	350
SPI EEPROM Library C Code	352
initSPI	354
SPI_tradeByte	355
Convenience Functions	356
Summary	357
17. I2C	359
How I2C Works	360
I2C Demo Hookup	364
I2C Demo Library	365
I2C Thermometer Demo	369
SPI and I2C Data Logger	371
Pointers in EEPROM	375
The UART Serial Menu	376
The Logger's Event Loop	377
18. Using Flash Program Memory	379
Using Flash Program Memory	379
Memory Addresses	381
The Address-Of Operator: &	382
Pointers	385
Pointers in Brief	385
Pointers as Arguments to Functions	388
Summary	392
Optional: Dereferencing Pointers	393
Talking Voltmeter	394
PROGMEM Data Structures and the Header File	395
Sound Playback and Voltage Reading: The .c File	400
Generating the Audio Data	404
Differential Pulse-Code Modulation	404
Encoding Two-bit DPCM	405
Encoding DPCM: wave2DPCM.py	408
19. EEPROM	413
Using EEPROM	414
Storing in Memory	414
Reading from Memory	419
Saving and Loading EEPROM	422

Organizing Data in EEPROM	423
Project: Vigenère Cipher Encoder/Decoder	426
20. Conclusion, Parting Words, and Encouragement	
.....	437
Learning AVR: The Missing Chapters	437
The Watchdog Timer	437
Power Savings	438
Crystals and Alternate Clock Sources	438
Bootloaders	438
Analog Comparator	439
Debugging	439
Put This Book Down and Build!	440
Index	441

Preface

Microcontroller projects are ubiquitous in the hobbyist/hacker/Maker world, and with good reason. Microcontrollers stand directly in the middle ground between the hardware world of buttons, motors, and lights and the software world of algorithms, connectivity, and infinite possibility. Microcontrollers are part computer and part electrical component. They can also be the metaphorical glue between the real world and the virtual world.

Why This Book?

Are you sending a balloon with a small payload to near space? Need a small bit of computing power to read your temperature sensors and accelerometer and log the data to an SD card without using too much power? A microcontroller is just what you need. Would you like to build your own small robot or a cute interactive toy for your niece? There's a microcontroller application there, too. I'm sure that you've seen a million interesting projects online, wondered, "How'd they do that?" and gotten the answer: a microcontroller. Without their capable microcontroller brains, the homegrown 3D printing scene would be nowhere. Microcontrollers are at the center of an emerging culture of people building the previously impossible.

The goal of this book is to get you building projects with microcontrollers and writing your own firmware (or using libraries from other people) in C. I've chosen the Atmel AVR series microcontrollers to focus on because they have a fantastic free and open toolchain, easily available programming hardware, and many of you probably have one or two already on hand in the form of Arduinos. A large part of the collaborative hacker community uses these chips, so it's as good a starting point as any. The ATmega168 chip family that we'll be using is right now the sweet spot in price-per-functionality, but it is not hard to port your code to smaller and cheaper if you want to or move over to other AVR chips if you need to.

I picked the C language because it's pretty much the standard for programming microcontrollers. It's just at the right point, for my taste, in terms of being abstract enough to read but low-level enough that turning an individual bit on or off doesn't require subclassing or overriding anything. Your C code will compile down to something that is nearly as efficient as the best-written assembler, but it's a heck of a lot easier to maintain. There's also a [ton](#) of code examples out there on the Web for you to look at and learn from. (That said, if you really want a good feel for how the hardware works, teach yourself AVR assembler when you're done with this book.)

On the other hand, this book is really a book about programming and using microcontrollers in general. Though the particular naming conventions and some of the implementation details are different across different brands of microcontrollers, the basic principles will be the same. More on this in just a minute.

Software Type or Hardware Type?

In a class on programming microcontrollers that I taught at my local hackerspace, I discovered that the students would identify largely as either hardware types or software types. Some people coded JavaScript for web applications all day, while others worked in electrical and machine shops. One guy had never seen a `for` loop, and another didn't know that the red wire is the positive side of a battery pack. Everyone had something to learn, but it was almost never the same thing for everyone.

In building your microcontroller projects, you're going to need to think both like a software type and a hardware type, even if only one of these initially comes naturally to you. At times you're going to need to debug code algorithms, and at other times you're going to need to figure out exactly what's going on electrically when that button is pushed or that motor is energized. This need to put on two different hats, sometimes even at the same time, characterizes microcontroller and embedded applications.

Throughout this book, there'll be some concepts that are too obvious to you, but which may be entirely perplexing to others. I'll be swapping my software-type and hardware-type hats accordingly. In the end, you'll become familiar enough with both worlds that you'll be able to navigate the middle ground. You'll know you've reached embedded-design nirvana when you begin coding [with](#) the hardware. Then you'll have become a microcontroller type!

Manifesto!

And so we come to my sincerest goal in writing this book instead of simply another blinky-LEDs-on-an-Arduino manual—to turn you into a true microcontroller type. Although the Arduino environment is good for getting people hooked on microcontrollers, it's a cheap high. Arduino/Wiring goes to great lengths to abstract away from the microcontroller's hardware. Here, I want to teach you [about the](#)

hardware—because it’s useful—so getting further away from it won’t help. (My friend Ash once described working with the Arduino environment as being “like knitting in boxing gloves.”)

I don’t think that the built-in hardware timer modules are something to be abstracted away from. I believe the timers should be understood thoroughly enough to be abused to create a small AM radio transmitter that can play the Mario theme song within a room using nothing more than a wire or your finger as an antenna (in [Chapter 9](#)). And I believe that this code should fit in under 500 bytes of program memory.

More seriously, many of the hardware peripherals inside the AVR are common to most microcontrollers, from the “prehistoric” 8051 or the tiniest PIC or ATtiny chips, through the MSP430s and the ATmegs, to the mighty Xmega and ARM chips. These hardware peripherals have been developed and honed over 40 years of microcontroller design development, and they’re not going away any time soon because they have been designed to be *helpful* to getting your project realized. The microcontroller hardware has been designed by very clever engineers to solve your problems. My goal in writing this book is to show you how common problems are solved. You need to learn the hardware, and apply the hardware, to love the hardware.

Although every microcontroller design implements things a little bit differently, once you’ve seen it here, it will make sense there. Every microcontroller that I’ve ever come across is programmable in C. Almost all of what you learn working through this book is *transferrable* to other chips and other architectures, because what you’re learning here is the way things work rather than an abstraction wrapped around the way things work, designed to protect you from the way things work. Some of what you learn (for instance bitwise binary manipulations in [Chapter 4](#)) might seem boring, but in the end it will give you simple and direct access to the common hardware bits that are put there to help you, and the techniques will work with any brand of microcontroller that you choose to use.

In short, almost none of the time you spend learning about how to create projects on the AVR in C will be wasted. Yeah, it’s a bit harder than just reusing someone’s shields and code. Yeah, you might need to stop sometimes and leaf through a C programming book or an electronics text (or just look it up on the Net). But when you find out that you need more processing power, or a different set of peripherals, you can just buy yourself a \$8 chip in place of the \$4 one you were using and bring most of your code, and more importantly your knowledge, along with you.

This book is meant to be the red pill, and I sincerely hope that you find it worth your time once you’ve seen how deep the rabbit hole goes.

You Will Need...

Before we get too much into detail about the AVR chips and what they can do for you, let me provide you with a shopping list. Order this stuff now so that you can be ready to start programming chips in a few days when the delivery truck shows up.

The Basic Kit

Here is a basic kit of parts that you'll need throughout the rest of your AVR life. A lot of this gear is multipurpose, and you'll have some of these parts on hand if you're playing around with electronics. The following is the basic kit that you'll use for programming AVRs throughout the book:

- A solderless breadboard or two or three. I like the 800-contact type because of the extra working space, but a few smaller breadboards can be nice for building subcircuits on. You can never have too much workspace.
- A number of wire jumpers to plug in to the breadboard. I really like the prebuilt ones with rubber grips and pins on the end. You can often find these sold in combination with breadboards for cheap at online auction websites.
- You should probably have a small resistor assortment on hand. You'll need a bunch in the 200–500 ohm range for LEDs, a few around 1k ohm, and at least five in the 10k ohm range.
- An ISP programmer (see [“Flash Programmers I Have Known and Loved” on page 28](#) for recommendations) or Arduino (see [“AVR and the Arduino” on page 20](#)).
- An ATmega168, 168A, 168P, or 168PA. Make sure you get one in the DIP package if you want to plug it into the breadboard. The parts I'm using at the moment are called ATMEGA 168A-PU, where the “PU” denotes a DIP part. See [“The AVR Family of Microcontrollers” on page 11](#) for more on chip selection.
- A USB-to-serial adapter. I'm a big fan of the FTDI USB-Serial cable. Get the 3.3 V-compatible one for maximum flexibility. It works painlessly with all operating systems, and at all speeds. A variety of online geekery stores have slightly cheaper options as well.
- At least 10 LEDs (any color) and 10 appropriately sized resistors: 200–500 ohms. You can never have enough LEDs.
- A source of 5 V DC power (optional). Many of the ISP programmers provide power to the breadboard. If yours doesn't, cutting up a 5 V wall-wart power supply or using a 4xAA battery pack will work. Rechargeable batteries are even better.

For the Basic Projects

- A small 8 ohm (normal) speaker and roughly 10–100 uF capacitor. I got my speaker from an old keyboard toy.
- Two or more pushbuttons. Normally open. Cheap tactile switches are great.
- At least 5x 2N7000 MOSFETs.
- Two light-dependent resistors (LDRs), but you might as well buy an assorted pack.
- Two potentiometers. 10k ohms is ideal. Anything above 1k ohms will work.

For the Intermediate Projects

- A piezo disk, preferably with wires attached.
- A servo. Any old hobby servo will do. I get my cheap ones from Tower Hobbies.
- A laser pointer that you're willing to take apart.
- An I2C device to talk to—my example uses the very common LM75 temperature sensor.
- An SPI device to talk to. Here, I'm using a 25LC256 32K SPI EEPROM chip.

For the Motors and H-Bridge Chapters

- A small DC motor (3–12 V is good). I got mine from a racecar toy.
- MOSFETs for building an H-Bridge. I use two IRF9530s and two IRF530s.
- SN754410 or L293D motor driver chip instead of or in addition to the MOSFETs.
- A stepper motor and a power supply to drive it.
- Random switch-like devices: relays, SSRs, Darlington transistors (TIP120, etc.).
- Random DC-powered devices like LED lamps or pumps or fans or solenoids or kids' toys or...
- A 5 V relay.

Deluxe and Frills

- A standalone voltmeter.
- An amplified speaker—computer speakers are ideal.
- A soldering iron and some solder.
- A prototype board for soldering up your circuits permanently.

- Extras of everything in the first list so that you can create permanent versions of each chapter's project that you like. Nothing beats having a bunch of souvenirs around to show off what you've learned and to go back to and modify later on.

Conventions Used in This Book

The following typographical conventions are used in this book:

Italic

Indicates new terms, URLs, email addresses, filenames, and file extensions.

Constant width

Used for program listings, as well as within paragraphs to refer to program elements such as variable or function names, databases, data types, environment variables, statements, and keywords.

Constant width bold

Shows commands or other text that should be typed literally by the user.

Constant width italic

Shows text that should be replaced with user-supplied values or by values determined by context.



This icon signifies a tip, suggestion, or general note.



This icon indicates a warning or caution.

Using Code Examples

Supplemental material (code examples, exercises, etc.) is available for download at <https://github.com/hexagon5un/AVR-Programming>.


This book is here to help you get your job done. In general, you may use the code in this book in your programs and documentation. You do not need to contact us for permission unless you're reproducing a significant portion of the code. For example, writing a program that uses several chunks of code from this book does not require permission. Selling or distributing a CD-ROM of examples from MAKE books does require permission. Answering a question by citing this book and quoting example code does not require permission. Incorporating a significant amount of

example code from this book into your product's documentation does require permission.

We appreciate, but do not require, attribution. An attribution usually includes the title, author, publisher, and ISBN. For example: "*Make: AVR Programming* by Elliot Williams (MAKE). Copyright 2014 Elliot Williams, 978-1-4493-5578-4."

If you feel your use of code examples falls outside fair use or the permission given here, feel free to contact us at bookpermissions@makermedia.com.

Safari® Books Online

 Safari Books Online is an on-demand digital library that lets you easily search over 7,500 technology and creative reference books and videos to find the answers you need quickly.

With a subscription, you can read any page and watch any video from our library online. Read books on your cell phone and mobile devices. Access new titles before they are available for print, get exclusive access to manuscripts in development, and post feedback for the authors. Copy and paste code samples, organize your favorites, download chapters, bookmark key sections, create notes, print out pages, and benefit from tons of other time-saving features.

Maker Media has uploaded this book to the Safari Books Online service. To have full digital access to this book and others on similar topics from MAKE and other publishers, sign up for free at <http://my.safaribooksonline.com>.

How to Contact Us

Please address comments and questions concerning this book to the publisher:

MAKE
1005 Gravenstein Highway North
Sebastopol, CA 95472
800-998-9938 (in the United States or Canada)
707-829-0515 (international or local)
707-829-0104 (fax)

MAKE unites, inspires, informs, and entertains a growing community of resourceful people who undertake amazing projects in their backyards, basements, and garages. MAKE celebrates your right to tweak, hack, and bend any technology to your will. The MAKE audience continues to be a growing culture and community that believes in bettering ourselves, our environment, our educational system—our entire world. This is much more than an audience, it's a worldwide movement that Make is leading—we call it the Maker Movement.

For more information about MAKE, visit us online:

MAKE magazine: <http://makezine.com/magazine/>
Maker Faire: <http://makerfaire.com>
Makezine.com: <http://makezine.com>
Maker Shed: <http://makershed.com/>

We have a web page for this book, where we list errata, examples, and any additional information. You can access this page at:

<http://oreil.ly/avr-programming>

To comment or ask technical questions about this book, send email to:

bookquestions@oreilly.com

Acknowledgments

I would like to thank the members of HacDC, and especially those who were subjected to my first couple of classes teaching microcontroller programming. I've learned as much from you all as you have from me. And you're all the inspiration for this book in the first place!

Special thanks go out to Gareth Branwyn and Alberto Gaitan for pushing me into writing this crazy thing. You are truly overlords and enablers. Respect!

To anyone who has contributed to the greater hive-mind that is the global hacker/Maker community: if you've put anything microcontroller-related out there, you've probably contributed to this book in a six-degrees-of-separation sort of way. I hope you enjoy it.

This book couldn't have been made without the help of the tremendous folks at O'Reilly and Maker Media. Patrick DiJusto edited the text with a fine-tooth comb and provided much helpful feedback. Brian Jepson, Shawn Wallace, and Dale Dougherty provided high-level direction. Kara Ebrahim helped pull it all together. Also, much thanks to Eric Weddington for his technical review. Writing a book is a team effort, and I thank you all.

Finally, my wife Christina has my endless gratitude for letting me see this long project through. Hab dich lieb, Schatz.

Programming AVR_s

2

Hello World!

In this chapter, you'll get set up with everything you need for coding, compiling, and flashing your programs into the bare silicon of the AVR chips that are sitting on your desk right now. To do so, you're going to need some hardware (a flash programmer) and some software (a code editor, C compiler, and the program that'll communicate with the hardware flash programmer). Finally, you'll need to hook up some wires from the programmer to the AVR chip and get set up with a power supply.

In this process, there are a *lot* of different approaches that will get you to the top of the same mountain. Ultimately, the different approaches are all basically the same at some abstract level, but we'll step through some details of a few of the most popular options to make things clearer.

On the hardware side, most of the flash programmers work about the same, and the differences there won't amount to much more than a few tweaks to a file that you'll use over and over again. Flash programmers, after all, are just USB devices that send bytes of your code across to the AVR chip. On the software side, different development packages will have different looks and feels, but in the end it all comes down to editing code, compiling it, and then sending it off to the hardware programmer.

Programming the AVR

The words "program," "programmer," and "programming" are overloaded in the microcontroller world. We (as programmers) write programs, compile them, and then use a flash programmer to program the AVR_s, which then runs our program. Pshwew! Let's step through the actual procedure and see what's actually going on.

What You Need

For this chapter, you'll just need the basic kit as described in [“The Basic Kit” on page xiv](#). For convenience, I've summarized that here:

- A solderless breadboard.
- Wire jumpers to plug in to the breadboard.
- An ISP programmer.
- An ATmega168, 168A, 168P, or 168PA.
- An LED (any color) and an appropriately sized resistor: 200–500 ohms.
- A source of 5 V DC power (if not supplied by your ISP); a 4xAA battery pack is nice anyway.
- One 100 nF (0.1 μ F) capacitor to smooth out the AVR's power supply.

Toolchain

It's a long and winding road from the code you type into your editor to a chip on your desk that turns a light on and off. Getting from typed letters on a computer screen to a working piece of electronic machinery requires a chain of tools called, predictably, a toolchain!

Toolchain overview

1. Write your source code in an [editor](#).
2. Turn your source code into machine code with a [compiler](#) (and associated software tools).
3. Using [uploader software](#) on your big computer and a [hardware flash programmer](#), send the machine code to your target AVR chip, which stores the instructions in its nonvolatile flash memory.
4. As soon as the flash programmer is done, the AVR chip resets and starts running your code.

[Figure 2-1](#) sketches out the main steps in AVR firmware development along with which tools you'll use for each step.

The first step in your toolchain is going to be a text editor, or whatever you're most comfortable writing code in. For the Linux folks out there, [gedit](#) is quite nice. On Windows platforms, you'll probably find the editor that comes with WinAVR, [Programmer's Notepad](#), will work pretty well, but I prefer the freeware [Notepad++](#). Many Mac coders swear by [TextMate](#). If you've already got a favorite code editor, by all means feel free to use it. Nice features to look for include syntax highlighting, automatic formatting and indenting, parenthesis matching, and maybe even code folding. (Put your copy of Microsoft Word away—that's not what we're looking for here.)




Figure 2-1. AVR programming toolchain

Aside on Windows Editors

Both *Programmer's Notepad* and *Notepad++* let you compile and flash code directly from the editor with a single button push, which is handy because the Windows command line isn't very familiar to most folks.

In *Programmer's Notepad*, there are options for calling your makefile in the Tools pull-down menu, and you'll see the results of your compilation and uploading in the "Output" panel at the bottom of the screen.

In *Notepad++*, use the Run pull-down menu, and type in `cmd /K cd /d $(CURRENT_DIRECTORY) &&`

make flash to open up a command window in the current directory, compile your code, and flash it to the AVR. The **/K** leaves the window open after it's done, so you can read any errors in compiling or uploading that may have occurred. You can also run it with **/C** if you don't want to see the output.

With both of these editors, you can also bind these actions to a key combination so that compiling and uploading your code is as easy as it would be in an IDE. Pretty slick.

Of course, if you want to get a whole IDE, I won't stop you, but it's not at all necessary. For Windows, Atmel Studio is comprehensive and centered on the task at hand. If you use Eclipse, there are AVR plug-ins as well. If you don't know what any of this means, skip this paragraph: learning a new IDE is itself a day's work, and too much detail to get into here. I don't recommend it when you're just starting out.

Anyway, once you can write and edit code, you need to compile it for the AVR, turning your human-readable C code into machine code for the AVR. The compiler we're using, `avr-gcc`, is the AVR-specific version of the popular open source compiler GCC. (In fact, I would argue that the support from Atmel for `avr-gcc` and an open source toolchain is the main reason for the chip's amazing success in the hacker community.)

In addition to the compiler, you'll need a few more software tools from the `avr-gcc` suite to go from source code to machine code that's ready for uploading. A script called a *makefile* is commonly used to automate all of the repetitive, intermediate bits of the process. See ["Make and Makefiles" on page 19](#) if you want to learn a little more about what's going on with the makefiles, but don't sweat it if it's too much info—you can do everything you need to by simply editing a few lines, and I'll walk you through that.

Once you've compiled your C code into machine code in the right format, it's time to send the machine code over to the chip and write it into nonvolatile flash memory. The *flash programmer* is a piece of hardware that sits in between your computer and the target AVR microcontroller. The AVR microcontrollers, when put into programming mode, listen over their serial peripheral interface (SPI) bus for incoming data to flash into program memory. The flash programmer's job is to relay the compiled machine code to the target AVR over the SPI bus. There are tons of flash programmers available, and I've listed some of my favorites in ["Flash Programmers I Have Known and Loved" on page 28](#).

A lot of you will have an Arduino sitting around. If so, it turns out to be fantastically easy to turn that Arduino (temporarily) into an AVR programmer. I'll walk you through the steps to do so, and how to wire it up, in ["AVR and the Arduino" on page 20](#). So if you don't have a dedicated hardware SPI programmer just yet, I'll get you up and running with an Arduino.

Now, stepping back to your main computer, you'll need to run software that feeds the compiled machine code to the flash programmer. Far and away the most popular software uploader is AVRDUDE, which is available for all platforms and supports a wide variety of programmers. How wide? So wide that almost any way that you can think of communicating in SPI with the target AVR will work with AVRDUDE, from a few wires hooked up to your parallel port to dedicated USB programmers with their own AVR microcontroller brains.

The Software Toolchain

The main feature of the style of software development that we'll use in this book is cross-platform compatibility. That is, if you're used to the whole workflow of writing code and compiling it on a Mac, you'll have the same tools available for you on Windows or Linux, and you can be sure that you'll always know what you're doing wherever you go. After all, the target of all our work here is a little 8-bit microcontroller that doesn't know anything about what operating system you use.

To Recap:

1. **Plan.** This stage just requires your brain, some paper and a pencil, and maybe the AVR data-sheet so you can figure out which parts the onboard hardware can help you with. Think through what you need the chip to do, and break it up into functions for each logical step.
2. **Code.** Write your program using whatever text/code editor makes you happy. Here you're just translating the ideas behind the functions into valid C code.
3. **Compile.** Turn your C code into AVR machine code with `avr-gcc` and its associated tools, most likely run from a makefile. Type **make** and read through the compiler errors, then go back and fix them.
4. **Flash.** Hook up a flash programmer to your target AVR and then run AVRDUDE to send the machine code through the programmer to the AVR chip, which saves it in flash memory. (Or just type **make flash** and watch it go.) Did flashing work?
5. **Test.** Once you've uploaded your code to the AVR, does it do what you want it to? Test it under many differing conditions before you're sure. You'll find all sorts of interesting real-world situations where your sensors aren't reporting data as you thought they would. Now's a good time to find that out, so you can recode around it.
6. **Debug.** There are many tricks for figuring out what's going wrong with your code—from lighting up status LEDs, to transferring variable data information over the serial line to your desktop computer, to stepping through the code with a debugger.

Programming the AVR—What's Really Going On?

AVR microcontrollers are able to write into their own flash program memory space. All of the ATmega series microcontrollers are set up so that when you reset them, they start listening for data on the SPI lines, and with the right instructions can program themselves.

A flash programmer works by grounding the RESET line, which halts the CPU and signals the AVR to start listening on the SPI bus. The programmer then transmits programming instructions over the SPI bus. After each instruction or section of code, the AVR writes the received data to flash memory. Some of the tiny AVR chips flash the data to program memory after every few bytes, which can be slow. Larger and newer

chips store the incoming data in a temporary page memory and then write it all at once, which is much, much faster.

After the programming is complete, you can read the data back out of the AVR's flash program memory to verify again that it's correct. The `-v` flag for AVRDUDE does this for you.

For a deep read on programming the AVR chips, for instance, if you want to implement your own flash programmer or write your own bootloader once you're done working through this book, see [Atmel's "Application Note AVR910"](#).

Linux Setup

Setting up the toolchain for programming AVR on Linux is tremendously simple. If you're using a Debian-based distribution (like Ubuntu or Mint or, heck, Debian) you can simply type (all on one line):

```
sudo aptitude install avrdude avrdude-doc binutils-avr avr-libc gcc-avr  
gdb-avr
```

Red Hat and Fedora users type:

```
sudo yum install avrdude avr-gcc avr-binutils avr-libc avr-gdb
```

All other Linux users will find that it's easy enough to find source packages for all of the above. See http://www.nongnu.org/avr-libc/user-manual/install_tools.html or http://avr-eclipse.sourceforge.net/wiki/index.php/The_AVR_GCC_Toolchain for details.

Windows Setup

Windows users have two options for the software toolchain, one based on the (huge) Atmel Studio and one based on WinAVR. Weighing in at 1/20 the file size and 9/10 of the functionality, I'd choose WinAVR. The current download link is from [SourceForge](http://sourceforge.net) and is a little bit old, though I've had no troubles with it. It's very well tested and fully debugged.

A hackerspace in Australia has taken up the task of making a more-recent WinAVR clone, and you can try your luck with <http://www.makehackvoid.com/project/mhvavrtools> if something in WinAVR doesn't work for you. (That said, I've never had any problems with WinAVR.)

During the installation, WinAVR will offer to change your PATH variable so that all of the binary files (importantly *make*, *avrdude*, and *avr-gcc*) are available without typing the full pathnames in. Be sure that you allow this.

Mac Setup

[AVR CrossPack](#) is the way to go for Mac. It includes all the compile tools, AVRDUDE, and more. It's kept up to date and should just work.

Arduino Setup

As a fourth option, the Arduino IDE is available for all three OS platforms. Heck, most of you will have it installed already. If you've got Arduino up and running, there are some modifications you can make to turn your Arduino IDE into a working generic AVR C-language environment. See ["AVR and the Arduino" on page 20](#) and, in particular, ["Writing C in the Arduino IDE" on page 24](#) for details.

If you'd like to use your Arduino as a hardware flash programmer, but don't plan to use the Arduino IDE, you can do that too. In addition to the Arduino install, install the software toolchain for your OS.

Make and Makefiles

The C programming language lets you split up one big program or task into a bunch of individual functions, and lets you keep collections of functions together in their own files for easier maintenance and portability. That way, if you want to frequently reuse some serial-port input/output functions, for instance, all you have to do is include the serial library code files (by name) in your main code, and then tell the compiler where to find these files. Separating your code into functionally different files is good software design, but it means that you need to remember all of the dependencies among the different files in your codebase and type out potentially many filenames each time you compile.

Keeping track of all of these dependencies manually can quickly become unreasonable, and it was only a few years after C was invented that the *make* utility was designed to help. Instead of compiling your files together manually, a file called a *makefile* contains a bunch of dependency rules and instructions for processing them, and then you just run the *make* command and everything compiles. (That's the idea, anyway.)

So, for instance, you can explicitly compile all of your source files together like this:

```
gcc main.c another_file.c serialLibrary.c -o main
```

which makes an executable file, *main*, from all of the listed *.c* files. Or, you can write a makefile that maps out these dependencies:

```
main: main.c another_file.c serialLibrary.c
```

and then simply type **make main** or even simpler, **make**. The *make* program knows that names on the left side of the ":" are targets, and on the right, their dependencies. If you need to run special commands to make the targets from their dependencies, these commands are listed on the next line, indented with a tab.

Dependencies can, in turn, have other dependencies, and *make* will keep digging deeper until it can resolve them. Things get complicated with makefiles when you add in variables and wildcards that match any filenames. You can start to write generic rules that compile any *.c* files together, for example, and then you only have to change the variable definitions when you move a makefile from project to project.

I'm including a preconfigured makefile for each project in this book's code repository. You may be able to use them as is, but we also might have different AVR programmers and different serial ports, so you'll eventually want to at least modify some of the definitions. We'll step through configuring the makefile to fit your setup in "[Configuring Your Makefile](#)" on page 38.

Now that you've got the software set up, all you need is to connect up a flash programmer to the chip and test it out. Here, you'll have two choices. If you don't have a dedicated AVR flash programmer yet, but you have an Arduino lying around, the next chapter is for you. If you'd like to buy a dedicated AVR flash programmer, I have some advice in ["Other Hardware Programmers" on page 28](#). Otherwise, if you've already got a flash programmer, you may proceed straight to ["Getting Started: Blinking LEDs" on page 29](#) and get started.

AVR and the Arduino

A bunch of you are going to be used to the Arduino programming environment. That's great! In this book, I'll be teaching you all of the powerful nitty-gritty that Arduino hides from you in the name of easy accessibility. But that doesn't mean that there's any reason to let your Arduino gather dust—in fact, the Arduino platform can be a great generic AVR playground, once you know how to (ab)use it.

Arduino Pros

One very real advantage of the Arduino hardware setup is that the chip comes pre-flashed with a [bootloader](#), which is code that enables the chip to communicate with your computer over the serial line in order to flash program itself. This means that you can do away with the requirement for an external bit of hardware to flash the chip—there's a tiny bit of bootloader code already running in your Arduino that'll flash the chip for you!

The second highlight of the Arduino package is that it comes with a built-in USB-to-serial converter, so you don't have to buy a separate one just yet. I personally get a lot of mileage out of my USB-Serial cable, and you will too if you want to play around with freestanding microcontrollers, GPS units, old terminals, hacked WiFi routers, and other devices. If you're going to get serious about embedded electronics hacking, you're going to want a standalone USB-Serial adapter eventually, but it's sweet that the Arduino lets you get away without buying one for the time being.

And finally, although it's not such a big deal, the Arduino is powered by your computer's USB power supply. This is handy if you're developing code on your laptop in a park or on a plane. You don't need to find a wall plug for your power adapter or remember to bring batteries along with you—all you need for flashing, communications, and power is a USB cable.

Arduino Cons

As good as the Arduino hardware is as a generic AVR development platform, it's not perfect. For use with this book and our examples, there are a number of disadvantages to using an Arduino instead of just plugging an AVR chip into a breadboard.

Probably the first among these disadvantages is the lack of the breadboard itself. Shields are great for finished products, but when I'm building up a hardware section for the first time, it's nice to test it out on something more flexible like a breadboard. I find that the more complicated my external circuitry gets, the less suitable working on the Arduino becomes. The Arduino is great for plugging a few LEDs or a couple of sensors into. But when things get interesting, I end up having to jumper the Arduino into the breadboard with 10 or more wires like some demented spider, and then my dog knocks something loose, and it takes a long while to debug the problem, and that's when I wish I'd just stuck a chip into the breadboard in the first place. (True story.)

Another downside to using an Arduino as an AVR development platform is that a few ports and pins are already irreversibly wired up and unavailable for use. For instance, when we make an eight-LED POV toy in [Chapter 3](#), you'll discover that two of the pins that I'd like to use for LEDs are already hard-wired up to the crystal oscillator. It's a design trade-off—because it's clocked with a 16 MHz crystal oscillator, the Arduino is able to run twice as fast as an AVR using only its internal timebase.

But because the Arduino ties up two of the pins in `PORTB`, you'll only be able to make a six-LED cylon without having to do some elaborate coding as a workaround. If you want to display a byte's worth of data on `PORTB`, you'll be missing the most significant two bits.

Arduino boards aren't cheap either; just compare an Arduino Uno with the AVR ATmega328p chip that powers it. You can buy 8 or 10 AVRs (or 20 ATtiny 45s) for the price of one Arduino. This is because the Arduino has extra hardware—power regulation, USB-to-serial, and other circuitry onboard—which makes them over-qualified for many trivial applications. This also makes an Arduino too expensive to commit to a one-off quickie project, and that's a real shame because nothing in the world is better than giving your young niece a goofy microcontroller-based toy that you made for around \$5 in parts. (That said, if you can prototype the toy faster because everything's wired up for you on the Arduino, go for it. A goal of this book is that you'll be able to move fluently between the "Real AVR" world and Arduino.)

More trivially, it's a minor pain to be always going back and forth between the pin names in the datasheet ("PB5" and similar) and the Arduino's pin names ("Digital 13" and so on). [Figure 2-2](#), which is similar to the sweet ASCII art in [arduino-1.0.4/hardware/arduino/variants/standard/pins_arduino.h](#), should help.




Figure 2-2. AVR pinout and Arduino labels

So if you're working along with code from this book, and you need an LED connected to pin PB0, for instance, you'll want to hook up the same LED to your Arduino's Digital 8 pin. (And see how the Arduino doesn't use pins PB6 and PB7?)

Finally, the Arduino bootloader needs to use the [watchdog timer](#), which is a timer that effectively reboots your AVR chip automatically if your code gets hung up and doesn't check in every once in a while. We won't even use the watchdog timer in this book, but if you need to make a very robust design, it's a nice trick to have up your sleeve.

But don't let these gripes overshadow the main point—an Arduino can also be turned into a fine C-language AVR-programming platform. And besides, if you've got one sitting on your desk, you might as well use it.

The Arduino: Hardware or Software? Both!

In the next two sections, I'll show you how to use the Arduino—both the software IDE *and* the physical hardware—as an AVR learning platform. The first section covers programming the AVR chip that's inside the Arduino (as you normally would) but using standard C instead of the strange Arduino dialect. This way, if you've already got an Arduino in hand, but AVR chips and a breadboard in the mail, you can get started working through this book by programming the Arduino board directly.

The second section treats the case where you've already got your AVR chip on a breadboard, and you want to use your Arduino as a hardware flash programmer to transfer the code to the target AVR. Following some simple steps, you can (temporarily and reversibly) use the Arduino as a hardware programmer to flash your code into the bare AVR. And then you can decide to continue using the Arduino IDE to compile and send your code, or you can use any other code editor and the standard AVR development toolchain. The choice is yours.

Choices, Choices!

From my perspective as an experienced coder and microcontroller user, I like to use my own favorite development tools rather than the Arduino IDE. It's also a lot easier and faster to prototype circuits with a bare AVR on a breadboard than using the Arduino hardware.

However, using the Arduino as a hardware programmer is tremendously comfortable, even if you're used to more advanced tools. With just six wires between the Arduino and your breadboard, you've got a

source of power and a flash programmer that's just as good as any other.

If you're willing to learn a bit more about the non-Arduino toolchain—programming in standard C, using makefiles, and all that—you'll be learning some transferrable skills that will work on other hardware platforms and microprocessor architectures. And then if you eventually swap out the Arduino-as-programmer for dedicated hardware, you won't even notice.

The Arduino Is an AVR

If you're shy about leaving the comfortable Arduino IDE, you don't have to. With a few tweaks, the Arduino compiler can be fooled into compiling standard C code, which you can then flash directly to the AVR that lives inside the Arduino hardware. So if you're coming from the Arduino world and you'd like to get started with this book right away—you can!

The reason that this all works is that the Arduino environment is really just a thin GUI layer that ties together the standard AVR toolchain—GCC as a compiler and AVRDUDE to talk to the flash programmer. In short, you can start off with the full Arduino IDE and slowly migrate over to doing everything manually, or vice versa.

Writing C in the Arduino IDE

If you're used to the Arduino IDE and don't want to try out another code editor, for instance, the following steps will enable you to compile and flash valid C code with minimal changes to your old workflow. Follow these steps whether you're programming for the Arduino's onboard AVR chip or for an external AVR target on a breadboard—anytime you want to write straight AVR C code within the Arduino environment.

To get running in C with the Arduino IDE, there are two things that you'll have to do only once, *before* you even start the IDE:

- Copy over whatever libraries you need to go with your code. In writing the code for this book, I ended up using a few bits of common code in almost every project. It makes more sense to put all of these common files in one place. To use this “library” of common code, create a directory in your libraries folder (`~/sketchbook/libraries` on Linux and `Documents/Arduino/libraries` on Windows) and copy your common code here. Now you'll be able to use it within any other program by simply by importing the library. So copy the *AVR-Programming-Library* folder out of the code directory and into your sketches library right now.
- If you're going to be coding for an ATmega 328P, either in an Arduino (the Uno, for instance) or as a standalone chip, fix up your *portpins.h* file. See “*portpins.h and the Arduino IDE*” on page 25. If you're going to use an ATmega168 or other chips, you don't have to follow this step, but it won't hurt.

Now that your Arduino IDE is set up, it's time to get coding. In this example, I'll assume that you'd like to copy some code out of one of the book's projects, but the same basic steps apply for when you're writing it yourself:

1. Start the Arduino IDE.
2. Import the header files into the project using the Sketch → Import Library pulldown, where you should find the *AVR-Programming-Library* folder at the bottom of the list. Notice that the Arduino IDE adds include lines for each header file in your directory.
3. Save this (mostly blank) sketch with a descriptive name. This will create a directory for you to put your code in.
4. Outside of Arduino, copy the C code file that you'd like to use into the sketches directory. If you press Open and reopen the sketch, you should see this newly added code in a new tab.
5. Alternatively, you can write new C code in the sketch by opening up a new tab (Ctrl-Shift-N, or from the arrow menu in the top-right corner) and then entering the code directly.

6. To make sure that all works, click on the Verify button. If it does, then you're ready to flash the code.

portpins.h and the Arduino IDE

The code compiler that the Arduino IDE uses is the same GCC as you'd use if you were compiling manually. As such, it doesn't care if you pass it code written in C for the AVR, or in C++, using the Arduino libraries. Along the way, though, I found a gotcha.

For whatever reason, the [portpins.h](#) include file that comes with Arduino 1.0.4 and previous is old (2006!) and doesn't conform to modern usage. The end result is that standard pin-name macros like PB1 don't end up getting defined for the mega328 chip, while the old-style PORTB1 macros are.

If you want to compile for an ATmega 328P chip (as is found on the Arduino Uno, for instance), you'll want to replace the [portpins.h](#) file with a more recent version. On my system, I found the file in [arduino-1.0.4/hardware/tools/avr/lib/avr/include/avr/portpins.h](#).

Replace this file with the version that I've included with the book's code library, and you should be able to just write C.

If you see errors like PB1 undeclared (first use in this function), that's the [portpins.h](#) bug.

Flashing the Arduino as target

This is super simple from within the Arduino IDE, because programming the Arduino is what it's meant to do. The only difference here is that you're writing your code in real, portable C rather than Arduinoese:

1. Verify that your board type is selected in Tools → Board.
2. Make sure you've included your library using Sketch → Import Libraries, and that the `#include` lines appear in the first sketch tab.
3. Click Upload (or type Ctrl-U) to flash your code into the AVR inside the Arduino hardware. Easy.

The Arduino Is an AVR Programmer

Or at least it can be. In this section, you're not going to be writing your code into the Arduino as a target, but rather using it as the middleman. You've got an AVR chip that you've stuck into a breadboard, and you're going to use the Arduino as the hardware programmer, thanks to example code that converts the Arduino into an Arduino In-System Programmer (ISP). You can do this either from within the Arduino software IDE, or you can use an editor and the `avr-gcc` toolchain independently.

Wiring your Arduino as a flash programmer

The first step toward using your Arduino as a flash programmer is hooking it up to your breadboard. The essential six connections are power, ground, RESET/PC6, SCK/

PB5, MISO/PB4, and MOSI/PB3. (You'll find these pin names in Figure 2-5 on page 2 of the AVR datasheet, or you can also just refer to [Figure 2-3](#).)




Figure 2-3. *Arduino as flash programmer*

The single red LED hooked up to pin PB0 on the target AVR is the LED in question if you're uploading this chapter's `blinkLED` code.

The three (optional, colored) LEDs hooked up to the Arduino are status lights. Green will pulse while the ArduinoISP is waiting for input, yellow will light when it's transferring code to the AVR, and red will light if there's an error. You can leave these out, but they make everything look so professional, no?

Resistor values for the LEDs aren't too critical, but something over 200 ohms is a good idea for normal LEDs, which commonly have around a 1.7 V threshold voltage, and are rated for around 20 milliamps: $(5\text{ V} - 1.7\text{ V}) / 220\text{ ohms} = 15\text{ milliamps}$.

Flashing AVR chips using the Arduino as a programmer

Now that the hardware is wired up, let's use it to program the AVR chip! Following these instructions will turn your Arduino into a flash programmer. (When you want your Arduino back as an Arduino, you can just reprogram it as usual.)

1. Verify that your Arduino board type is set up correctly (Tools → Board → Uno in my case).
2. Flash the example code "ArduinoISP" into the Arduino hardware the usual Arduino way.

3. If you don't have a sketch ready to upload yet, go back to [“Writing C in the Arduino IDE” on page 24](#) and set up [blinkLED.c](#).
4. Select Tools → Programmer → Arduino as ISP to program [through](#) the Arduino hardware instead of programming the Arduino itself.
5. Select Tools → Board → Arduino Pro Mini (8 MHz) w/ ATmega168, because we're targeting an ATmega168 running at 8 MHz. (Nobody will know it's not inside an Arduino Pro.)
6. [Shift](#)-click on the Upload button (Shift-Ctrl-U) to flash your code into the AVR target. If you're too accustomed to just clicking the Upload button and forget to press Shift here, you'll get an error like `avrdude: stk500_disable(): protocol error, expect=0x14, resp=0x10`.
7. If you want to see what's going on in the background, click File → Preferences → Show verbose output.
8. Otherwise, sit back and watch your AVR target get programmed. Does it blink? Sweet!

Using Arduino as hardware programmer without the Arduino IDE

Because it's possible to use your Arduino as a flash programmer from within the Arduino IDE, you're probably wondering if it's possible to flash arbitrary AVR chips without using the Arduino IDE as well. Of course it is!

First, make sure that your Arduino is wired up as in [Figure 2-3](#) and that you've uploaded the `ArduinoISP` sketch to the Arduino. Once you've done that, you won't need to touch the Arduino IDE again if you don't want to.

Open up the [blinkLED](#) directory from the software that accompanies this book. Because you're using makefiles to configure and compile your code, you're going to need to edit [Makefile](#) by hand so that it knows how to use the Arduino programmer. In short, you want to use programmer type “avrisp” at 19,200 baud on the correct serial port.

For Linux, try:

```
PROGRAMMER_TYPE = avrisp
PROGRAMMER_ARGS = -b 19200 -P /dev/ttyACM0
```

For Windows, try:

```
PROGRAMMER_TYPE = avrisp
PROGRAMMER_ARGS = -b 19200 -P com5
```

For Macintosh using the Uno or Mega 2560, try:

```
PROGRAMMER_TYPE = avrisp
PROGRAMMER_ARGS = -b 19200 -P /dev/tty.usbmodemXXXXXXX
```

For Macintosh using any other Arduino, try:

```
PROGRAMMER_TYPE = avrisp
PROGRAMMER_ARGS = -b 19200 -P /dev/tty.usbserialXXXXXX
```

You can figure out which port name the Arduino connects to from within the Arduino environment, under Tools → Serial Port. On Windows systems it will be a COM port, and on Linux or OSX systems it will be `/dev/tty-something`.

Once your makefile is configured for the Arduino-as-programmer, you're all set to flash the code over to your chip. If you've got a terminal window open, and you're in the *blinkLED* directory, typing `make flash` should do it.

Other Hardware Programmers

If you don't have an Arduino handy, or if you'd like the convenience of a dedicated hardware flash programmer, you've got a lot of good choices. If you've got the software already set up, a flash programmer is your missing link. (If you already got your firmware flashed by following the previous Arduino instructions, you can skip this section, or read on for curiosity's sake.)

Flash Programmers I Have Known and Loved

You have a large number of choices for hardware flash programmers. A programmer can be as simple as a couple of wires, but most of them actually use an AVR or other microcontroller to interface between your computer and the AVR that you'd like to program. Here is a shortened list of some of the good choices you have available:

Parallel port

The first programmer I ever used was not really any programmer at all, but instead just a cable with five wires soldered to a parallel port D-sub connector. This works because AVRDUDE knows how to toggle the lines of a parallel port to program your AVR chips directly. Unfortunately this programming method requires a parallel port on your computer, which is a luxury that fewer and fewer of us have. On the other hand, if you'd like to go this route, search the Web for a DAPA (Direct AVR Parallel Access) cable. Many of the schematics will include "safety" resistors—feel free to ignore them unless you're hooking up your AVR to voltages higher than 15 V. If you've got an unused parallel printer cable lying around, you've got your first programmer.

Atmel AVRISP mkII

Atmel's current official USB in-system programmer, the AVRISP mkII is a very nice programmer that's capable of programming the whole AVR line, including the newest X-Mega devices. It's a bit more expensive than other programmers, but it's rock solid and is quite a bargain all in all.

USBTiny and USBasp

These two USB-based AVR programmers have super simple hardware designs with open source firmware. You can make one yourself, although you will iron-

ically have to find a way to flash the firmware into the AVR in the programmer (an Arduino ISP is perfect for this). You can also find these designs for sale all over—I’ve got a USBasp-based programmer that I bought for \$5 online, and it’s just fine. Both of these designs have a jumper that allows you to power your breadboard off of your computer’s USB port, which is handy for most applications in this book.

LadyAda’s USBTinyISP

This is an improved version of the USBTiny, with input and output buffering. I’ve used one of these for a few years. They come in kits, don’t cost too much money, and have very good build instructions and support. Like the USBTiny project that it’s based on, LadyAda’s programmer can power your project off the USB bus. If you’d like an easy kit to solder together that builds a useful tool, this is a good way to go.

A family portrait of some of my programmers can be found in [Figure 2-4](#), from center-top and going clockwise:

1. An Arduino and six wires makes a totally workable flash programmer.
2. USBTinyISP
3. USBasp, from BaiTe in China
4. USBTiny, tiny version from ehajo.de
5. A homemade programming spider, which plugs into a breadboard around the AVR chip and connects up the programming, power, and reset pins the right way every time. If you’re at all handy with a soldering iron and perfboard, you should make one of these.

Getting Started: Blinking LEDs

OK, let’s get down to business and compile, flash, and test our first AVR microcontroller project. This is *not* the coolest, most interesting project in this book. The point is to verify that all parts of the programming toolchain are working for you before we start to get a little fancy. In order to minimize the possible ways to mess up, we’ll build up the simplest possible project that puts the software toolchain together with the flash programmer, an AVR chip, and the most minimal possible feedback—a single LED.

To download the code for this project—and for the rest of the book—visit <https://github.com/hexagon5un/AVR-Programming> and click the “Download ZIP” button. The blinking LED example is in this chapter’s folder.

Please double-check that you’ve installed an appropriate software toolchain for your OS, or modified the Arduino environment to work with C language code. If

you're using an Arduino as a hardware programmer, make sure that you've flashed ArduinoISP. Fasten your seatbelts—here we go!




Figure 2-4. *Some programmer options*

Hookup

The overview of wiring for this chapter is that we're going to be hooking up the programmer (including its power-supply pins) to the AVR chip. Each of these pins has a specific function, and they're labelled in [Figure 2-5](#). The whole point is to make sure that the programmer's MOSI pin is connected to the AVR's MOSI pin (PB3) and so on. We'll also wire up an LED for display purposes, and optionally wire up another as a power-on indicator.

If you're using an Arduino as your programmer, your wiring will end up looking like [Figure 2-3](#), but you can also assemble the circuit piecewise as we're doing here. First hook up the power and verify that it's working, and then move on to the MOSI, MISO, SCK, and RESET wires. The principle is exactly the same.

For the first step, let's set up the power rails of your breadboard to double-check that we've got the pinout from the programmer's connector right. You're going to need some red wire for 5 V and some black wire for GND. If you're using an Arduino as programmer, the 5 V and GND connections are nicely labelled on the board. Use red and black wires to hook them up to the breadboard's power rails.

ISP Connectors




Figure 2-5. AVR ISP programming pins

If you're using a programmer that ends in a standard 6-pin or 10-pin two-row IDC connector, getting the pinout correct can be a little bit tricky. For orientation, set the connector on the table so that you're looking down into the holes, and notice the location of the plastic tab. The cable should also have a red stripe on the same side that has the VCC pin, which is a very helpful mnemonic. Hook up the power pins so that they look like [Figure 2-6](#).

If you're going to use a power-on LED, now's the time to plug it into the board to verify that you've got power. Wire it up as in [Figure 2-7](#). Note that LEDs are *polarized*, and you'll need to make sure that the positive side is connected to VCC and the negative side to ground. You can recognize the negative side of an LED by its shorter pin (think of it as the "minus" side having something *subtracted* from its length), or by the slight flat spot on the flange of round LEDs, or by the larger structure inside the LED itself. Connect the resistor up to the negative pin.

Plug your USB programmer into your computer. If the LED glows, the power supply is ready to go. If not, and you're using a programmer like the USBTiny, you may have to install a jumper across two pins to enable the power-supply passthrough. (See the instructions that came with your programmer for how to make the programmer supply power to the AVR.) If this still isn't working, double-check your 6-pin connector again. After you've gotten the power-on LED light working, you know for sure that you're getting power on the breadboard's supply rails.




Figure 2-6. AVR programmer layout—no chip yet

Now plug the AVR somewhere in the middle of the board. Locate pins 7 and 8, which are power and ground for the chip, and plug a 100 nF (0.1 μ F) capacitor across the two power pins. Using a red wire, connect pin 7 to the VCC rail. Wire up pin 8 with a black wire to the GND rail. Now you've completed the setup in [Figure 2-7](#).




Figure 2-7. AVR programmer layout—power

Now hook up the rest of the programmer's pins. Look carefully at [Figure 2-5](#) if it's not clear which pins are which. Double-check that MOSI on the connector is wired to MOSI on the AVR, etc. Finally, connect up the demo output LED and its resistor as shown in [Figure 2-8](#). When you're done with this, we're ready to test it out.




Figure 2-8. *BlinkLED full setup*

ISP Headers

The Atmel-standard 6-pin and 10-pin headers are nice for manufactured boards because they're compact, but they're not at all breadboard-friendly, and that's why we end up with all these wires all over. Sparkfun (and probably others) sell adapters that convert the 5×2 and 3×2 layouts into a 6×1 inline layout that plugs nicely into the breadboard and labels the signal lines as well. If you're ever placing an order with them, these little tools are well worth a dollar.

Alternatively, you can take some perfboard and wire up a similar breakout yourself. You'll need a bunch of breakaway header pins, a bit of wire, and some patience. Make sure you test and label the outputs when you're done.

For the long run, I'd recommend making yourself a programming adapter of some kind. The idea is to hardwire up a connector that either plugs into a breadboard or sits on top of the chip that you can use to replace the multiple wires that connect the programmer to the chip. [Figure 2-9](#) demonstrates a variety of ways to simplify connections between your AVR and programmer.




Figure 2-9. Programming adapters for ISP 6-pin headers

From the top, going clockwise:

1. A USBTiny programmer with the standard 6-pin ISP header.
2. A zero insertion force (ZIF) socket that I wired up to connect to the 6-pin ISP header and the ATmegax8 series chips. For fun, I also added a power-on LED and an external power connection so that it can work with nonself-powered flash programmers. You can find ZIF sockets cheap at online auction sites. The underlying perfboard came from Radio Shack.
3. Next is a (deluxe!) custom board that I had made as a precursor to a board I used in teaching an AVR class. This one breaks out all the ports into banks, has a 6-pin SPI header, an external power connector, on-board capacitors and power lights, and a 6-pin inline header that's compatible with the FTDI USB-Serial cable pinouts.
4. On the bottom is an experimental 6-pin ISP adaptor that just barely squeezes on top of an AVR chip, holding itself in place by bending the pins a little bit. I got the idea from http://elm-chan.org/works/avr/x/report_e.html, but I added on a serial interface as well. It's hard to maintain contact with all the pins at once, and I only use this connector in emergencies.
5. Last, on the far left, is the homemade programming spider that I use almost all the time. It plugs into a breadboard just around the AVR and connects up everything you need to flash the chip. It's the bee's knees, and if you're handy

with a soldering iron or looking for an excuse to learn, making a connector like this is well worth your time.

AVRDUDE

After you've gotten the circuit breadboarded and the AVR connected up to the programmer, you're ready to start talking to the AVR to test the connection. And, believe it or not, the easiest way to do this is to type a little bit.

Open up a command-line window. If you're in Linux or Mac OS, open up Terminal. For Windows, open up a Run dialog from the Start menu, type in `cmd`, and hit Enter. You can then type `avrdude` to double-check your installation. You should see a helpful listing of all the command-line flags and arguments that you can use. You can read up on the most useful ones in ["AVRDUDE Options" on page 35](#).

If you don't get AVRDUDE running from the command line, you're going to need to make sure that it's installed and that your OS knows the correct path to find it. If you're on Windows, the easiest way is probably to uninstall WinAVR and reinstall, allowing it to set up the PATH variable for you this time. Linux and Mac people should not have this issue.



Drivers and Windows

If you're running Windows, you may not automatically have the correct drivers for your programmer installed. This is notably the case with Windows Vista and Windows 7 and the USBTiny and USBasp type programmers. If you get a warning message like "usbtiny device not found," it's very likely that your drivers aren't set up right.

You should probably follow whatever instructions your programmer comes with. For me, I had to download a newer `libusb` from LadyAda's website, install it, and then do a manual install of the USBTiny drivers through the Device Manager. This step is no fun, but you only have to do it once.

Now let's try to talk to the programmer directly. Type something like `avrdude -p m168p -c usbtiny` to interrogate the chip (only substitute your programmer in place of the "usbtiny") and optionally add a serial port and baud rate. If all is hooked up well, it will respond with something about the chip's signature and fuses and say OK. Success looks something like this:

```
avrdude: AVR device initialized and ready to accept instructions
Reading | ##### | 100% 0.01s
avrdude: Device signature = 0x1e9406
avrdude: safemode: Fuses OK
avrdude done. Thank you.
```

AVRDUDE Options

Whoa! That's a lot of choices. Let's look at a few of the ones that we'll use:

-c <programmer>

Here you specify the type of flash programmer that you're using. Many serial programmers, including the ArduinoISP, use the generic avrisp type (not the arduino type, which programs the Arduino itself). There are also configurations for both usbasp and usbtiny programmers. If you'd like to see the full list, type **avrdude -c ?**.

-p <partno>

Here you specify the type of AVR chip that you're programming for. In our case "m168" is an ATmega168 chip or "m168p" if you've got that version.

-P <port>

If you're not using a native USB programmer (for instance, if you're using an ArduinoISP), you'll need to know which serial port the programmer is connected to. See "[Common AVRDUDE Configurations](#)" on page 38 for details. On Windows, it's usually something like COM3; on Linux and Mac OS, it's in the /dev/tty* lineup.

-b <baud>

This sets the baud rate if you're using a serial programmer. You'll have to know what speed your programmer wants, or use trial and error.

-n

Write-nothing mode. This one lets you test out commands without worrying that you'll accidentally mess up the chip.

-t

Terminal mode. This mode lets you talk to the AVR chip directly. After the programmer has connected, type **sig** to read the AVR's device signature, which makes a quick test of basic communication between the programmer and chip. Type **help** to see all the options.

-C <config-file>

This lets you use a nonstandard configuration file. If the version of AVRDUDE that you've got doesn't support a particular chip or programmer, you can often fix it by getting a more recent configuration file. I've included mine in the book's software bundle.

-U

This the command that reads or writes to memory. You'll almost always be calling this from a makefile, but if you'd like to dump the memory of an AVR chip to a file, or flash in a [.hex](#) file that someone has already compiled for you, this is how you'd do it.

AVRDUDE errors

On the other hand, you might get an error. There are basically four possible errors you'll get, depending on whether you've messed up the wiring, specified the wrong chip or programmer type, or don't have adequate permissions to use the interface. Let's break them down into cases.

You get an an error that reads:

```
avrdude: initialization failed, rc=-1
      Double check connections and try again, or use -F to override
      this check.
```

The dreaded rc=-1 error message means that your wiring is messed up. Despite what it suggests, using -F won't help you—99.9% of the time when you see this

error, your problem is that the six wires connecting your programmer to the AVR chip aren't hooked up right. This error can occur when you don't have power to the chip, when any of the RESET, MISO, MOSI, or SCK lines aren't connected properly, or even if you've got something else plugged into any of these pins that's interfering with your setup. Double-check everything until the problem is fixed; maybe even unplug and replug your USB programmer.

You get an error that reads:

```
avrdude: Device signature = 0x1e9406
avrdude: Expected signature for ATmega168P is 1E 94 0B
Double check chip, or use -F to override this check.
```

This probably means that you've got the AVR chip type wrong. In the previous example, I used a mega168 but told it I had a mega168P. In this case, you just need to change the chip type that you're passing as an argument to AVRDUDE. If AVRDUDE doesn't have a configuration for the chip you're using, you should try using a newer (or custom) configuration file with the `-C` flag (see ["AVRDUDE Options" on page 35](#)).

The other source of the Expected signature error is that there's something wrong with the communication channel. If the programmer sees a signature like `0xffffffff` or `0x000000` or the signature changes from one trial to the next, you've most likely got something wired up to your ISP lines that's blocking the communications, or you've got a loose wire. Fix these problems and try again.

You get an error that reads:

```
avrdude: stk500_recv(): programmer is not responding
avrdude done. Thank you.
```

or:

```
avrdude: error: could not find USB device with vid=0x16c0 pid=0x5dc
vendor='www.fischl.de' product='USBasp'
```

or:

```
avrdude: Error: Could not find USBtiny device (0x1781/0xc9f)
```

This means AVRDUDE is having trouble finding your programmer. In the case of a serial programmer like when you're using the Arduino, double-check the serial port and baud-rate flags that you're passing to AVRDUDE. If you're using a USB programmer, make sure that it's recognized by the system. On Linux you can type `lsusb` and look for the programmer in the list. On Windows, check for it in the Device Manager.

Finally, if you're on Linux and you receive a permissions error, you can fix it by typing **sudo avrdude** instead of **avrdude**. When you get tired of the extra typing, you can give yourself permission to write to USB serial ports. In Ubuntu-like distributions, this means adding yourself to the `dialout` group. For all flavors of Linux you could

alternatively write a [udev](#) script for the specific programmer. You'll find specific directions online if you search "avrdude udev" and your programmer type.

Common AVRDUDE Configurations

AVRDUDE supports more than 70 programmers and 100 chip types, and runs on three different operating systems, so the number of possible configurations is ridiculous. Here are some examples of the types of configurations that you'll encounter to get you started:

Windows, Linux, or Mac OS with USBTiny, ATmega168P

```
avrdude -p m168p -c usbtiny
```

(Because USBTiny and USBasp programmers don't need any additional options, the command is the same across all three operating systems.)

For the following, you need to type the commands all on one line:

Windows with ArduinoISP, ATmega168p

```
avrdude -p m168p -c avrisp -P com5  
-b 19200
```

Linux with ArduinoISP, ATmega168p

```
avrdude -p m168p -c avrisp -P  
/dev/ttyACM0 -b 19200
```

Mac OS with ArduinoISP, ATmega168p

```
avrdude -p m168p -c avrisp -P  
/dev/tty.usbserial-A5307bQf -b 19200
```

ArduinoISP needs the `-P` flag for the serial port. To find out which serial port you need, open up the Arduino IDE and look under Tools → Serial Ports with the Arduino plugged in. (The Arduino plugs into USB, but it's got an onboard serial emulator that makes it show up as a serial port device.)

Windows with parallel port programming cable, ATmega88

```
avrdude -p m88 -c dapa -P lpt1
```

Linux with parallel port programming cable, ATmega168p

```
avrdude -p m88 -c dapa -P /dev/parport0
```

I hope these examples get you squared away, or at least put you on the right path. If not, an Internet search will probably yield results. In most all situations, just a couple of tweaks to the same basic command options will work.

Configuring Your Makefile

Playing around with AVRDUDE by itself is good for debugging and making sure everything works, but you'd hate to have to remember all this, much less type this all out every time. And that's where the makefile comes in.

As mentioned in "[Make and Makefiles](#)" on [page 19](#), most of the makefile is generic info for the compiler about how to compile and link program files for the AVR, and you'll never need to modify these generic bits. On the other hand, the top few lines include some definitions that are specific to the project at hand and to your compilation and flash programming setup. We're going to need to edit some of these by hand. Copy the [blinkLED](#) folder from the book's source code library and open up [Makefile](#) with your programming editor. Let's step through the bits you'll need to change:

MCU

This is the type of AVR chip you're using. In our case, we're using an ATmega168, so it reads `atmega168`. For a complete list of supported chips, type **`avr-gcc --target-help`** and about halfway down you'll find a list of "Known MCU names."

F_CPU

This definition tells the compiler what clock speed your chip is running at. If you don't have an external clock source, like a crystal, this is either 1,000,000 or 8,000,000 for the ATmega chips—one megahertz or eight megahertz. Getting this right will matter for the timing of serial communication, and anything else where timing is key.

BAUD

This is the baud rate that you're going to use for computer-to-AVR serial communications, and 9,600 baud is a good conservative default.

MAIN

This entry is just the name of the program that you're compiling and flashing—the code that contains the `main()` routine. I've filled this in for you in the book's projects, but if you want to start a new project from scratch but reuse this makefile, you'll need to change the **MAIN**.

LOCAL_SOURCE

Here you have the chance to list any other `.c` files that your main code section needs to run. Again, I've filled these in for the book's projects, but I mention it here in case you'd like to see how to include multiple files in your compilation.

EXTRA_SOURCE_DIR and EXTRA_SOURCE_FILES

This is an option to include code that lives in another directory or folder somewhere on your system. We'll use this a lot for including my `USART.h` standard serial library.

PROGRAMMER_TYPE

The two "programmer" options are for AVRDUDE, along with information about what chip we're programming from MCU. Here, you enter the type of flash programmer that you're using, and the makefile passes it to AVRDUDE using the `-c` option. If you're using a USBTiny or USBasp, for instance, you enter that here. If you're using the Arduino as a flash programmer, enter **`avrisp`**.

PROGRAMMER_ARGS

The other "programmer" option is for any of the other necessary AVRDUDE options. If you're using a USBTiny or USBasp, you won't have to enter anything here; just leave the line blank. If you are using a serial-based programmer, you'll need to specify the serial port and baud rate using the `-P` and `-b` options, respectively.

See “[Common AVRDUDE Configurations](#)” on page 38 for hints, or scroll down to the very bottom of the makefile to see some examples for common programmers and configurations. And remember, this is just passing these options on to AVRDUDE, so whatever it took to get AVRDUDE working on the command line (except for processor and programmer type), you’ll need to add in here.

Flash

OK, by now you’re dying to see some blinking lights. I can’t blame you. If you’ve already got a command-line window open, change directory to the `blinkLED` project and type **make flash**. If all of the preparations up to now went well, congratulations! Your sweet reward is a slowly blinking LED on the breadboard!

You want more? Open up the `blinkLED.c` file in your editor, and read through. Try changing the delay times to change the blink rate of the LED—for instance, make it blink on for just a very short time between long periods of being off. Each time you edit the code, save it and then type **make flash** again. Or if you’re using an editor that lets you compile and flash from within it, it’s even simpler.

Take the time now to get used to the “edit-compile-flash” cycle, while the toolchain is unfamiliar but the code is simple. Once the code and/or the circuits start to get complicated, you’ll be glad to have faith in the toolchain.

Troubleshooting

We did most of the troubleshooting for this project as we went along. Is the power working? It should be, as long as the power LED is lit. Does the AVR receive this power? A quick way to double-check is to put an LED across the AVR power pins, where you’ve got a capacitor.

The next things to check are the connections, because it’s easy to get these wrong. But because we tested them using AVRDUDE, we know that the programmer is able to communicate with the AVR chip, so all should be well.

So with the hardware all debugged, that only leaves the software, and in this case, it’s about as simple as can be. What’s more, I’ve double-checked it about a billion times, so it should compile just fine. (Barring the `pindefs.h` problem if you’re using an Arduino IDE for compiling, in which case see “[portpins.h and the Arduino IDE](#)” on page 25.)

Because everything’s working just fine, a good exercise at this point is to break the code and see what happens. C compilers are great when it comes to complaining *that* something’s wrong, but not as helpful as you’d like when it comes to pin-pointing the *cause* of the error. For instance, pick a line of code that ends with a “;” and delete the semicolon. Save the bad code and type **make** to see what happens. All sorts of errors, no? But none of them tell you “you deleted a semicolon.” Learning to deal with the error messages is an important part of coding.

If you deleted a semicolon as suggested, you'll probably see an error like:

```
blinkLED.c: In function 'main':  
blinkLED.c:22:5: error: called object '_delay_ms(1.0e+3)' is not a function
```

The compiler is telling you that something went wrong around line 22 in the code, specifically something that starts at line 22, column 5. It doesn't know there's a missing semicolon, but it gets you in the right neighborhood. This is where you have to do a little detective work. (The meaning of the error is that lines that look like `something()` without a semicolon at the end are supposed to be function definitions, but in this case it's not. The compiler can't know that you meant [use](#) a function rather than define one if you don't add that semicolon on the end.)

It could be worse. Sometimes there will be a string of many errors all in a row. Don't give up! It's not necessarily the case that you made many errors, but maybe the first one caused a bunch of follow-on problems to arise. If the compiler gives you multiple errors, it's often a good idea to start fixing the first one (by line number) and then see if that resolves the rest.

Anyway, fix up that semicolon and reflash your valid code with a `make flash`. Notice what a successful flashing looks like. Heck, if you're feeling nerdy, scroll back up to see the exact string of commands the makefile ran on your behalf and revisit ["Make and Makefiles" on page 19](#). If you just want to get on with more programming, and everything worked, we're done here.